

ALU complete skidplate for Can-Am Outlander 500/570L Max

Model: 500/570L MAX

Product code: 800-00-05



Thank you for purchasing a set of SHARK Accessories skidplate. SHARK skidplate is made of extremely strong, durable and lightweight aircraft-grade aluminum, and are precisely designed and manufactured for specific model. Their installation therefore does not require any drilling or any other modifications. The covers require professional installation. We recommend contacting an authorized SHARK dealer for installation.

Each manual applies only to a specific ATV model and may not be the same as the installation procedure for other ATV models. In case of doubt, please contact your SHARK dealer or the official distributor: ASP Group s.r.o.

Fasteners

SHARK chassis covers are supplied with fasteners. Bolts, nuts and washers required for assembly are divided for individual covers in bags. To avoid confusion and mixing of fasteners, it is recommended to always unpack the fasteners only for the cover currently being assembled.

When assembling and disassembling the covers:

- Remove the original plastic covers from the chassis and front and rear A-arms.
- Always tighten the screws partially by hand first so that you can align the covers accurately. Only then tighten the screws tightly one step at a time.
- When fitting the A-arm covers, ensure that there is sufficient clearance between the A-arm cover and the cover to prevent the two covers from coming into contact even when the wheel is fully extended.
- Do not over-tighten the cover screws to avoid stripping or damaging the threads.

Tools needed for assembly:

Socket wrenches 10 and 14 mm, Allen wrenches 4 and 5 mm.

Safety warning:

We recommend wearing protective gloves when mounting and dismounting the covers to avoid injury from any sharp edges of the cover.

Can-Am Outlander 500/570L MAX

